



PORTABLE BEARING PACKER

The Portable Bearing Packer works on bearings up to 89mm [3-1/2"] outside diameter. The grease stays in the tool cavity, not on your hands. To pack a bearing, place the bearing on the piston Press down on the cap until the old grease is forced out and the new grease shows on top of the bearing
Part No. PST-72775



SCREW EXTRACTOR KIT - 5 PIECE

- Forged alloy steel, this tapered style extractor can be used to extract broken studs, screws, pipe and pipe fittings.
- Has gradual taper and long flutes.

Part No. PST-65000



HEAVY DUTY OIL FILTER STRAP WRENCH


- This deluxe wrench adjusts quickly to any spin-on filter.
 - Features 3/8-in. and 1/2-in. forged driver and heavy duty strap for high torque requirements.
- Handles filters up to 9-in. (228mm) especially high torque requirements on truck and tractors
Part No. PST-27800

TOOL GRIPPER WRENCH RACKS

Manufactured from flexible rubber as opposed to stiff plastic. The rubber flexes around the wrench to hold it in place at virtually any angle. Very durable and won't crack or split like plastic versions. Manufactured in the USA.




Part No.	Description
PST-5040E	4 pce wrench rack - RED
PST-5080E	7 pce wrench rack - RED
PST-5015E	12 pce wrench rack -RED
PST-5013E	13 pce wrench rack - RED
PST-5088E	15 pce wrench rack - FLURO
PST-5188R	15 pce reverse wrench rack -RED
PST-5072E	7 pce wrench rack <u>Stubby</u> - RED
PST - 5082HV	15 pce wrench rack - FLURO
PST-5500E	10 pce plier organiser - RED



REVERSE Wrench Rack



Stubby Wrench Rack



Pliers Organiser



STANDARD Wrench Rack